

SHAD

BENELLI TRK 502 '17 KIT TOP B0TR57ST



1 262095 x1



2 260213 x4
Ø16 Ø9 x 12



3 303017 x6
Ø6



4 302021 x4
M6



5 304079 x2
M6 x 30
Din 7380



6 304029 x2
M6 x 35
Din 7991

! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

