


SHAD

VOGE 500 DS '20 TOP MASTER VODS50ST



1 262693 x1



2 260417 x1
Ø16 Ø9 x 16



3 303045 x3
Ø8



4 304169 x1
M8 x 50
Din 7380



5 304032 x2
M8 x 50
Din 7991



6 260740 x2
Ø20 Ø11 x 11



7 262694 x2



8 302024 x2
M8

! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT soit correctement positionné et ajusté.

